


# Important!

The TourSCAN® bar-code scanner is a contact reader. This means that the tip of the TourSCAN unit must make contact with the bar-code strip in order to get a "read."



(Use the above picture for reference.)

For best results:

- ☞ *Hold the TourSCAN unit back at a slight angle.*
- ☞ *Place the tip against one end of the bar-code strip to be read.*
- ☞ *Press down on the button.*
- ☞ *With a slight, but constant pressure, swipe the TourSCAN tip across the bar-code.*
- ☞ *Listen for the beep -- the green LED will illuminate to confirm a good "read."*

**Caution:** Reflections from bright sunlight can occur which may result in bad "reads." Do not mount station labels in locations where direct sunlight will be shining during use.